



N°	Désignations	Références
1	Plateau inox / All stainless steel pan	021.018.092
2	Lexan arrière / Rear overlay	33020
3	Carte afficheurs LCD / Front display LCD	500602041
4	Lexan avant afficheurs / Front overlay displays	33035
5	Lexan clavier / Keypad Overlay	33034
6	Capteur Zemic 9880 / 9880 Zemic Load cell – 3kg/0.05g <i>Capteur Zemic L6D-C3-5kg-0.4B-P2</i>	1060382
	Capteur Zemic 9880 / 9880 Zemic Load cell – 6kg/0.1g <i>Capteur Zemic L6D-C3-8kg-0.4B-P2</i>	1060383
	Capteur Zemic 9880 / 9880 Zemic Load cell – 15kg/0,2g <i>Capteur Zemic L6D-C3-20kg-0.4B-P2</i>	1060384
	Capteur Zemic 9880 / 9880 Zemic Load cell – 30kg/0,5g <i>Capteur Zemic L6D-C3-35kg-0.4B-P2</i>	1060385
7	Carte principale CPU / CPU Complete mainboard	500609032
8	Batterie / Battery <i>6V 4.5AH/20HR</i>	590.003
9	Pied réglable / Leveling feet	30840
10	Bloc d'alimentation / Power supply <i>100-240V 50/60Hz 0.4A - 12V-800mA</i>	618-9880



B3C pesage

Sérénité



SAV

☎ 01 64 99 34 34